

1. Fix the LH & RH drawer clips to the underside of the timber drawer box using 4x '1"x6 screws'. Ensure the clips are flush to the front edge & tight against the drawer sides.

2. Locate the drawer box on to the drawer runners & slide back until it "clicks" in position. Ensure the drawer runner lugs are secured in to the holes on the back of the drawer box .

3. To release the drawer box squeeze both drawer clip handles & gently pull the drawer off the runners.

4. To attach the drawer frontal fix through the holes in the front of the drawer box using the 'pan head screws' provided .
*Note - The handle will require fixing to the frontal prior to fixing to the drawer box, If using a slab frontal 'countersunk M4 bolts' are provided to ensure the frontal sits flush against the drawer box.